



CLEANING ISTRUCTIONS FOR DMG PRODUCTS

Many **DMG** products are made of **polycarbonate** parts (currently featuring Bayer's **Makrolon**). Products currently featuring this type of material are:



Pushbuttons and Indicators series *BL, BD, BF, B7, BW, BP, BS, BR*



Position Indicators for car and landing panels, with polycarbonate screens



Other plastic components (*Arrows, Emergency lamps, etc.*)

To ensure proper cleaning of its products and to avoid damages to plastic parts caused by aggressive cleaning agents, DMG recommends to follow these instructions:

	Clean the part with cotton rug and warm water before applying the cleaning product
	Use PH-neutral or slightly acid cleaning products only (including aromatised ones) Ethylic alcohol, isopropilic alcohol or glycol ethylene-based multipurpose cleaning products and dish soaps are suggested
	Dilute the cleaning product in warm water and apply using a wet cotton rug
	Grease, glue and paint may be removed with ethylic alcohol or isopropilic alcohol after the part has been cleaned with a wet rug and warm water



Warnings:

DO NOT use abrasive or alkaline cleaning agents, not containing benzene, ammonia or methanol

DO NOT use sharp tools to remove dirt (chewing gum, glue,)

DO NOT use benzene

DO NOT use cleaning agents at high temperature

DO NOT leave cleaning agents on the part for long periods: remove immediately after cleaning using wet cotton rug and warm water

DO NOT use dry cotton rugs and sponges



Recommended Products ():**

Italia	U.K.	France	Deutschland	España	North America
Per Vetro, Windus- Brial Top- Ecolab	Per Vetro, Windus- Brial Top- Ecolab	Per Vetro, Windus- Brial Top- Ecolab	Per Vetro, Windus- Brial Top- Ecolab	Per Vetro, Windus- Brial Top- Ecolab	
Folax Prontocarb- Tuto Chimica s.n.c		Mr Proper Surfaces Delicates- P&G	Mr Proper Allzwickreiniger- P&G	Don Limpio Ph neutro-P&G	Joy (Procter & Gamble)
Hygenist Multiuso, Bayer					

(**) Due to the vast offer of cleaning products available on the market, the list of recommended products above is illustrative only

DMG SpA • Via Quarto Negroni, 10 • 00040 CECCHINA (ROMA) • ITALIA

Tel. +39 06930251 • Fax +39 0693025240 • info@dmg.it • www.dmg.it